

CONNECTING SOLAR PANELS

1600 BRIEFCASE KIT

**ONLY FOR POINT ZERO ENERGY SOLAR PANELS.
DO NOT USE this wiring diagram with any other solar panels.**

- A- Titan Power Module
- B- Titan 2000 wh battery pack
- C- Anderson to MC4 adapter
- D- MC4 extension cable
- E- Branch connector
- F- 15 ft. MC4 extension cable
- G- 200 watt briefcase solar panels

