

Titan Boost

STEP 1: CONNECT BATTERY

1. Ensure the power switch on both the Titan Power Module and all batteries are turned **OFF** (in the out position).

 Stack the Power Module on top of one battery pack, making sure the rubber feet are aligned on top of the circle indentations of the battery pack.
Tighten the four metal latches on the sides of the battery pack. You may need to press down on the generator to close the latch.


4. The battery is now connected.



Turn on all batteries by ensuring the button on each battery is pressed in.
Turn the Titan Power Module to ON.
Install the app using the appropriate QR code.
Using the app, program the meter to the combined AMP-HOURS of ALL battery packs that will be in use:

a) Determine the total amp hours of batteries connected. Each LFP battery is 90ah. For example, if you have 3 LFP batteries, your total amp hours is 3 x 90= 270 ah.

b) Open your app on your phone, select the gear icon to enter the settings. Enter the correct amp hours and select update.








STEP 3: FULLY CHARGE BATTERY

 If not already on, turn all batteries and the Titan Power Module ON.
Fully charge the battery using the provided AC charger until the LED light on the charger turns green. The AC charger can be left to charge as it has a shut off feature which will not over-charge the batteries.



IMPORTANT: DO NOT rely on the percentage reading of the meter at this stage. The Titan meter will not read an accurate state of charge until all steps 1-3 are completed.





SCAN FOR FULL USER MANUAL

