


**ONLY FOR POINT ZERO ENERGY SOLAR PANELS.
DO NOT USE this wiring diagram with any other solar panels.**



BEFORE CONNECTING SOLAR TO THE TITAN, check the voltage of your solar panels with the included volt meter while in direct sunlight. IF VOLTAGE IS OVER 120V, DO NOT CONNECT TO THE TITAN.